
ATTENTION! VOLTAGE ALSO PRESENT WHEN PSU IS TURNED OFF

NEVER DISCONNECT FIELD COIL WHEN OPERATING!



THE MODULE IS NOT SHORT PROOF

A SHORT OR MISSUSE IS NOT COVERED BY WARRANTY