













@ 2.0ADC







FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain



FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain




FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain




FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain


@ 4.0ADC




-18.17 dB, 5137 Hz (263), 0.000 msec (1)
ESC exits, F1 prints, Shift-F1 dumps, F2 places cursor MLSSA: Waterfall




-16.77 dB, 5137 Hz (263), 0.000 msec (1)
ESC exits, F1 prints, Shift-F1 dumps, F2 places cursor MLSSA: Waterfall




-15.69 dB, 5137 Hz (263), 0.000 msec (1)
ESC exits, F1 prints, Shift-F1 dumps, F2 places cursor MLSSA: Waterfall



-14.86 dB, 5137 Hz (263), 0.000 msec (1)
ESC exits, F1 prints, Shift-F1 dumps, F2 places cursor MLSSA: Waterfall




FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Ma
Overlay Calculate Printer DOS Units Library Inf
F1 for Help



FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Ma
Overlay Calculate Printer DOS Units Library Inf
F1 for Help


@ 5.0ADC



-14.12 dB, 5137 Hz (263), 0.000 msec (1)

MLSSA: FrequenESC exits, F1 prints, Shift-F1 dumps, F2 places cursor



MLSSA: Waterfall



-13.50 dB, 5137 Hz (263), 0.000 msec (1)



MLSSA: FrequenESC exits, F1 prints, Shift-F1 dumps, F2 places cursor

MLSSA: Waterfall





FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain

FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain



FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain

FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain



FREQUENCY DOMAIN MENU: Go View Reference Acquisition Setup Transfer Macro QC
Overlay Calculate Printer DOS Units Library Info Exit
F1 for Help MLSSA: Frequency Domain

TIME DOMAIN MENU: Go View FFT Waterfall Acquisition Setup Transfer Macro
Overlay Calculate Printer DOS Units Library Info Quit
F1 for Help MLSSA: Time Domain

comparision 0.5ADC ... 5.0ADC

[illegible]